

Bilge Mate (BGWS-01)

The BGWS-01 displays voltage and current draw of the attached pump and includes two additional alarm inputs that can be configured around your vessel's needs.

1. Power In

9 - 36 Vdc

2. Ground

Supply Negative = Ground = Boat Chassis

3. Pump In

Pump power output from float switch

4. Pump Out

Power to pump (15 Amps Max)

5. Digital Alarm 1

0-36 Vdc

Active-High or Active-Low

6. Digital Alarm 1 Ground

Supply Negative = Ground = Boat Chassis

7. Digital Alarm 2

0-36 Vdc

Active-High or Active-Low

8. Digital Alarm 2 Ground

Supply negative = Ground = Boat Chassis

