

# GPS / Geofence Mate (BGWS-00)

The BGWS-00 includes two additional alarm inputs that can connect to motion detectors, open / close sensors for doors and hatches, and other alarms.

## 1. Power In

9 – 36 Vdc

## 2. Ground

Supply Negative = Ground = Boat Chassis

## 3. No Connect

## 4. No Connect

## 5. Digital Alarm 1

0-36 Vdc

Active-High or Active-Low

## 6. Digital Alarm 1 Ground

Supply Negative = Ground = Boat Chassis

## 7. Digital Alarm 2

0-36 Vdc

Active-High or Active-Low

## 8. Digital Alarm 2 Ground

Supply Negative = Ground = Boat Chassis

## 9. Antenna Connector

External GPS Antenna

