

Oil and Fuel Alarm Sensor (SM-OIL)

Oil / Fuel Alarm Output | Digital Alarm Input

Black = Ground

Supply Negative = Ground = Boat Chassis

Red = Power In

9 - 36 Vdc

Use 2 Amp fuse

Yellow = High Water Alarm Output

Connect to alarm light/buzzer

1 Amp Max

Purple = Digital Alarm Input

Active-High or Active-Low

0 - 36 Vdc

