ABOUT TEMPERATURE SENSOR

1 Temperature (Internal/External)

1 Humidity

2 Digital Alarms (Active High or Low)

1. Power In

9 - 36 Vdc power

2. Ground

Supply negative = Ground = Boat chassis

3. Temperature Signal

Yellow Wire

4. Temperature Power

Red Wire

5. Temperature Ground

Black Wire

6. Digital Alarm 1


Normally Open or Closed 0-36 Vdc 24-12 AWG Wire

7. Digital Alarm 2

Normally Open or Closed 0-36 Vdc 24-12 AWG Wire

8. Digital Alarm Ground

Supply negative = Ground = Boat chassis



Battery One

1 Amp Fuse